

## UNIVERSAL RAI® SERIES BLOWERS PARTS LIST

Item No.	Part Name	Qty.
1	Headplate Gear End	1
2	Headplate Drive End	1
3	Gearbox	1
4	Gears	1
5	Cover-Blind (Plug Opening)	1
7	Gasket	1
9	Nameplate Lube	1
14	Bearing G.E., - Driven	3
15	Bearing Drive D.E., - Drive	1
16	Pin, Dowel	4
17	Gear Nut	2
19	Key	1
20	Screw, Self Tap	1
21	Plug, Pipe	3
23	Screw Hex	6
25	Breather (Plug Vent)	1
26	Screw, Hex	14
27	Seal	4
29	Washer - wavy Spring	2
30	Washer	8
31	Screw, Hex	4
32	Screw, Hex	4
33	Seal Lip-Drive	1
34	Clamp Plate	2
35	Foot	2
36	Foot	2
37	Fitting, Grease	2
38	Fitting, Relief	2
39	Washer Flat	4
40	Screw Socket	2
40*	Screw, Button Hd.	4
42	Screw Hex	2
43	Plug	8
44*	Washer	4

\*For 32 and 42 URAI-G only.